





The *Bow Coach* is a unique training aid that detects movement of the bow as the shot is being made and displays it graphically, giving you **instant feedback after every shot**. Training with the *Bow Coach* will help you develop a consistent shot follow through and ultimately **make you a better shooter!**



Example of movement during shot follow through:



Example of no movement (steady bow hand):



Visit www.bowcoach.com to register your *Bow Coach*, get product updates, or to view the entire BuckEye Cam product line.



BuckEye Cam

Athens Technical Specialists, Inc (ATSI)

8157 US Highway 50, Athens, OH 45701, USA

Controls and Display


RECALL button

Push this button to recall the display of the last shot.

ARM button

Push this button to activate the *Bow Coach*.

ON/OFF switch



Top Limb Motion display

Top lights – forward motion
Middle lights – start position
Bottom – backward motion


Level display

Top lights – left tilt
Middle lights – level
Bottom lights – right tilt

Attaching the Bow Coach to Your Bow

The *Bow Coach* attaches to the riser of any bow that is equipped with the standard accessory mounting holes. It may be attached directly to the bow, or to the quiver mounting holes available on most bow sights.

Attach directly to bow riser or to bow sight.



Use the supplied screws. Do not over tighten.

Using the Bow Coach


1. Nock the arrow.
2. Push the "ARM" button. The red light on the button will come on.
3. Draw your bow, aim, and shoot.
4. The vibration of the shot will trigger the *Bow Coach*.
5. After the arrow hits the target, view the results on the display.

Top Limb Motion

The Top Limb Motion (upper window) display indicates forward motion of the bow (toward the target) or backward motion (toward the shooter). The motion is always shown relative to the starting position.


Level

The Level (lower window) display shows how the bow tilts left or right.




Examples

Example of movement during shot follow through:



Example of no movement (steady bow hand):



Skill Level

To change the skill level, press and hold the RECALL button for 3 seconds. The current level will be displayed. Continue holding the button to change to another level. Release the button when the desired level is displayed.

The sensitivity of the *Bow Coach* to movement of the bow increases with each level (L-1 is least sensitive, L-3 is most sensitive).

Batteries

The *Bow Coach* requires 3 AAA batteries (not included). To prolong battery life, turn the power switch off when you are not using *Bow Coach* for a long period of time.

WARNING! Do not mix old and new batteries. Only install the same battery type.

Helpful Hints

- After the ARM button is pushed, you have up to 1 minute to take a shot. When drawing your bow, avoid sudden jerks as these may falsely trigger the *Bow Coach*.
- The Top Limb Motion Display always indicates forward or backward movement from the starting position. For example, the bow arm may be angled down before the shot. This position will be taken as the starting point and forward/backward movement will be shown relative to this starting position.
- **All of the center lights illuminated after the shot is an indication of no movement detected during the follow through (steady bow hand).**