



www.buckeyecam.com

Bow Coach Special Modes

Extended Trigger Delay Mode

In this mode, there will be a 6 second delay after the ARM button is pushed. This delay is indicated by the flashing red ARM light. During this delay, the Bow Coach will not trigger. This delay will give the user time to draw the bow without accidentally triggering the Bow Coach by the vibration of the draw. This mode is useful for bows that have hard cams.

To put the Bow Coach in the Extended Trigger Delay Mode :

1. Turn the power switch off.
2. Hold down the ARM button.
3. Turn the power switch on while still holding the ARM button.
4. Continue holding the ARM button until you see the red arrow go across the display.

If at some point you would like to put the Bow Coach back into the normal trigger mode, repeat steps 1 - 4. You can always know what mode you are in by observing the red ARM light. If the light flashes when the ARM button is pushed the Bow Coach is in the Extended Trigger Delay Mode. If the light is on steady when the ARM button is pushed the Bow Coach is in the Normal Trigger Mode.

Calibration Mode

To ensure that the Bow Coach is working accurately, it is important to calibrate it from time to time. The Bow Coach should be calibrated before use if it has not been calibrated in the last 30 days.

To calibrate the Bow Coach :

1. Turn the power switch off.
2. Place the back of the Bow Coach against a flat and level vertical wall.
3. Hold down the ARM and RECALL buttons.
4. Turn the power switch on while still holding down the buttons.
5. Continue to hold down the buttons.
6. After about 10 seconds, the display will show a number countdown and then OK.
7. Release the buttons when you see OK.

The Bow Coach is now calibrated and ready for use.

Visit www.buckeyecam.com to find video demonstrations of the Bow Coach special modes as well as other useful tips.



8157 US Hwy 50 • Athens, OH 45701 • 866.325.8172
740.592.2874 • Fax 740.594.2875 • sales@buckeyecam.com